




THINKDIAG



1 Download the ThinkDiag App

Search for "ThinkDiag" in the App Store or in Google Play Store.
The ThinkDiag App is FREE to download.



2 Login or Sign Up

If you already have a Thinkcar Tech account, please LOGIN with your credentials. If you do not have an account, please sign up as instructed in the following paragraph. Please note that one Thinkcar Tech account is in common use for all products by Thinkcar Tech.


How to Sign Up for an Account:

Open the ThinkDiag App, click on "Sign Up". Input your username, email, and verification code (which will be sent to the email you input), then create your own password. Click on "Sign Up" to finish your registration.

A screenshot of the login form. It features two input fields: 'Your Email Address' with an envelope icon and 'Password' with a lock icon and a toggle for visibility. Below the fields is a large red 'LOGIN' button. At the bottom, there are links for 'Sign up' and 'Forget Password'.A screenshot of the sign-up form. It features four input fields: 'Enter Email Address' with an envelope icon, 'Enter 4-6 digit code' with a shield icon and a 'Verification code' label, 'Password must be 6 digits or long' with a lock icon, and 'Confirm Password' with a lock icon and a toggle for visibility. Below the fields is a large red 'Sign Up' button.

3 Activate a ThinkDiag Device

After your registration, you need to input the serial number and an 8-digit activation code, for your ThinkDiag device.





S/N is on ThinkDiag OBDII connector

Activation code is on the first page of the Quick Start Guide


4 Download Diagnostic Software

After activating your ThinkDiag device, as explained in the previous part, go to the "ThinkStore" to download the diagnostic software. Please select the software that corresponds to your vehicle.



5 Plug ThinkDiag Device into the OBDII port in your vehicle:

Usually, the OBDII port is located under the dashboard, above the pedal on the driver's side. Here are the 5 common positions for the OBDII port (as shown in the figure below). Plug ThinkDiag device, there will be a green light which indicates the device is powered on.



6 Bluetooth Connection

Open the ThinkDiag App, it will automatically search for activated devices, select your device and connect to it via Bluetooth in the App.

7 Start to Use Your ThinkDiag Device

After the bluetooth connection, you can use all the functions of your ThinkDiag device, such as: All Systems Diagnostics, Maintenance&Service Functions, OBD II Diagnostics, Thinkcar Remote Diagnostics.

ALL SYSTEM
FULL FUNCTIONS



MAINTENANCE
FUNCTIONS



OBD FUNCTIONS



THINKCAR REMOTE
DIAGNOSTICS



8 FAQ

1. Q:What do the different lights on ThinkDiag indicate?

A:There are four different lights on ThinkDiag:

Continuous Green Light: ThinkDiag device is powered on.

Continuous Blue Light: Bluetooth is connected.

Flashing Blue Light: Bluetooth is in communication.

Continuous Red Light: Firmware upgrade successful or firmware upgrade failed.

2. Q:Why do I need to download the diagnostics software after downloading the App?

A:Due to a variety of vehicle manufacturers on the market, different vehicle manufacturers require corresponding diagnostic software. Therefore, ThinkDiag will recognize the vehicle manufacturer first while diagnosing, then it will download the corresponding diagnostic software to work.

3. Q: What vehicles can ThinkDiag diagnose?

A:ThinkDiag supports 37 vehicle manufacturers, diagnoses more than 110 vehicle brands. The diagnostics software for the different types of vehicles, is available in the ThinkStore in the ThinkDiag App. Note: Depending on your vehicle the diagnostics software size varies. Some diagnostics software downloads are longer which requires a good connection.

4. Q:What are the special functions of ThinkDiag?

A:ThinkDiag supports 16 special functions, including: AFS RESET、

Elec.Throttle RLRN、 GEAR LEARN、 Immobilizer/Keys、 INJECTOR、

RESET BRAKE、 RESET OIL、 RESET SAS、 RESETBLEED、 RESETBMS、

RESETBOX、 RESETDPF、 RESETEGR、 RESETTPMS、 SUNROOF、

RESET SUS. According to different vehicle manufacturers' diagnostics software, there will be more special functions to come.

5. Q: What is the bonus point of the THINKCAR account? How to use it?

A: Every user can get points. For example, by recommending others purchase our products, participating in Thinkcar Tech's official activities, etc. One point redeems one dollar, which can be used to purchase products and services. There will be more ways to get collect points in the near future.

6. Q: What is the invitation code in ThinkDiag App? How to use it?

A: After signing up for your account in the App, you will get your own invitation code. The code can be shared with your friends and they will get a discount. Every time the invitation code is used, you will get points as mentioned in the previous part.

7. Q: Does ThinkDiag need firmware upgrade?

A: Yes, it does. When the ThinkDiag device is connected via bluetooth to your smartphone, it will automatically check if the firmware on your device is the latest version. If it's not, it will upgrade automatically.

8. Q: What smartphone is compatible with ThinkDiag App?

A: ThinkDiag App supports smartphones with Android 5.0 and above, IOS 9.0 and above. It cannot be used on PC with WINDOWS system.

9. Q: Can the same App account bind with multiple devices?

A: Yes, you can set them up in the App.

9

Warranty Card

1. In addition to the legal withdrawal right, you benefit from a 30-day money back guarantee.

The device is also guaranteed for a period of one year.

2. Before replacement, please ensure complete packaging; Before replacement/repair, please call the service number to get the shipping address.

3. Product warranty starting date is based on the payment date.

Service Line: 1-833-692-2766

Customer Service Email: support@thinkcarus.com

Official Website: www.mythinkcar.com

Products tutorial videos, FAQ and coverage list are available on Thinkcar official website.

Follow us on Facebook: [@thinkcar.official](https://www.facebook.com/thinkcar.official)

Twitter: [@ObdThinkcar](https://twitter.com/ObdThinkcar)

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.